
# **INSTALLATION GUIDE**

# **MAIN DETAILS**


# **Hole Size**

Please ensure the hole cutter is 42mm. If the PIR is forced into the ceiling it can be damaged and become difficult to remove.




# Surface Mounting

For installation we can supply a surface mounting tube (product code: LC-PIRBB).




# Required Clearance

The PIR will need 37mm clearance for the connections, to ensure the cables don't get damaged or flattened.



# **Precaution**

Care should be taken to not press on the lens when installing to avoid damaging the PIR.



#### **PRODUCT TYPE:**

Presence Detector



LC-DALIPIR2



#### FOR DATASHEETS:

www.lightingcontrols.ltd.uk


# **CONNECTING THE PIR**

# Max amount on a DALI circuit


2-wire: max =10

4-wire: max =15

Note: the number of PIRs will be reduced if other devices (for example, Scene Plates) are connected to the same circuit.



## 2 Wire connection



## 4 Wire connection

